

SHUTTER INSTALLATION INSTRUCTIONS

Dear REBUILD Northwest Florida Customer:

Please follow these installation instructions for your hurricane storm panels. All openings are numbered counter-clockwise, starting with the first opening on the front left corner of your home. Please see the attached photo layout of your home.

For steel or aluminum panels:

1. Remove all caps.
2. Start at the bottom of each opening.
3. Place panel over the four (4) lowest PanelMates.
4. Secure two bottom slots onto PanelMates with washered wing nuts (provided with panels).
5. Place bottom of second panel over two (2) top PanelMates of the first panel.
6. Secure with washered wing nuts.
7. Repeat steps 1 through 5 until opening is completely covered.

For Fabric Shield:

1. Remove all caps.
2. Start at the top left corner of the opening and place grommet over shutter pin.
3. Begin to thread washered wing nut (do not tighten all the way).
4. Working across and down, repeat step 2 until panel fully installed.
5. Tighten all washered wing nuts.

ALWAYS WEAR LEATHER WORKMANS GLOVES WHEN HANDLING PANELS